



# E-Z Roller Waffle Cone Former

Model No. 5028


## Installation Instructions

Your E-Z Roller Waffle Cone Former is fully assembled, except for the (4) Crutch Tips and Handlegrip. Thoroughly wash the cone roller and mandrel in mild soapy water (DO NOT use harsh automatic dishwashing detergents) and rinse before using. Slide the crutch tips on each of the base feet, and slide the handlegrip on the mandrel.

## Operating Instructions

After removing the cooked waffle cone from the baker, immediately insert it into the cone roller. It should overhang the front edge slightly and be pushed about halfway around the form. Insert the mandrel and gently push toward the cone tip as you twist the mandrel counterclockwise. After the disc is completely rolled, let it sit while you pour another cone. This helps cool and “set” the cone.

## Parts List



Item	Part Description	Part No.
1	WAFFLE CONE ROLLER	<a href="#">76274</a>
2	MANDREL, CONE ROLLER	<a href="#">76276</a>
3	HANDLEGRIP	<a href="#">76338</a>
4	CRUTCH TIP BLACK 70 DURO	<a href="#">49123</a>